




INSTRUCTION MANUAL

Remote Meter: MT50



Important Safety Instructions

SAVE THESE INSTRUCTIONS:

This manual contains important safety, installation and operating instructions for the Remote Meter.

General safety information

- Please inspect the MT50 thoroughly after it is delivered. If any damage is seen, please notify the shipping company or our company immediately. A photo of the damage may be helpful.
- Read all instructions and cautions in the manual before starting the installation.
- Keep the MT50 away from rain, exposure, severe dust, vibrations, corrosive gas and intense electromagnetic interference.
- Do not allow water to enter remote meter.
- There are no user serviceable parts inside the controller. Do not disassemble or attempt to repair it.

Contents

1. General Information	1
1.1 Features	1
1.2 Main functions	1
1.3 Recommendations	1
2. Installation	2
3. Product Features	5
4. Operation	8
4.1 Buttons	8
4.2 Main menu	9
4.3 Real-time monitoring	9
4.4 Device information	10
4.5 Test operation	11
4.6 Control parameter	11
4.7 Load setting	13
4.8 Device parameter	15
4.9 Device password	16
4.10 Factory reset	17
4.11 Failure information	17
4.12 Meter parameter	18
5. Technical Specifications	19

1. General Information

1.1 Features

The new-generation remote display unit MT50 for the controllers is an associated display device which supports both the latest communication protocol and the voltage technology standard of solar controllers. The products have many excellent functions:

- Automatic identify and display the type, model and relevant parameter data of controllers;
- Real-time display the operational data and working status of the connection devices in digital, graphic and textual forms by a large-screen multifunction LCD;
- Direct, convenient and rapid operation of six navigation function keys;
- Both data and power flowing on the same lead, no need for external power;
- Real-time data monitoring and remote load switchover of the controllers, and data browse and modification of device parameters, charge control parameters and load control parameters;
- Real-time display of failure information of the connection devices;
- Longer communication distance based on RS485.


2.2 Main functions

Functions like the real-time monitoring of the operational data and working status of a controller, the browse and modification of charge/discharge control parameters, the setting of device parameters and load control parameters and the restoration of factory defaults, based on LCD display and functional key operation.

2.3 Recommendations

Please do not install MT50 in a situation with strong electromagnetic interference.


2. Installation



Mechanical parameter	Parameter
Overall dimension	114 x 114 x 48.2mm
Mounting dimension	88.6 (3.49) x 88.6 (3.49) mm/ Zoll
Terminal	Φ5


Wall installation steps:

- **Step1:** Locate and drill screw holes based on the Frame Mounting dimension of the base, and erect the plastic expansion bolts;
- **Step 2:** Use four ST4.2x32 self-tapping screws to fix the frame;



Frame Mounting


- **Step 3:** Use four M4x8 pan head screws to mount MT50 Surface on the frame;
- **Step 4:** Mount the four associated screw plugs into the screw holes.



Surface Mounting

Steps of surface mounting:


- **Step 1:** Locate and drill screw holes based on the installation size of the surface;
- **Step 2:** Use four M4×8 cross recessed pan head screws with M4 nuts to mount MT50 Surface onto the panel;
- **Step 3:** Mount the four associated white screw plugs into the screw holes.




Surface mounting

Note: Take full consideration of the plugging/unplugging space of the communication cable and the length of the cable during installation to see if they are appropriate.

3. Product Features



RS485 communication and power interface



➤ Failure indicator

Failure indicator flashes in case of failure of the connection devices. For failure information please check the Controller Manual.

➤ Communication indicator

Indicate communication status when MT50 is connected with the controller.

➤ Display screen

Man-machine interaction operation interface.

➤ Buttons


The Meter buttons include four navigation buttons and two operational buttons. See the specific directions in the Operational Manual.

➤ RJ45 communication and power interfaces

Communication and power supply cable interfaces, used for communication connection with controllers.

- **Note:** Please use the communication plug which is marked with “MT” to connect MT50

Monitoring screen



Day and night icons



-Night,



- Day: The threshold voltage is 1V. Higher than 1V is daytime.

Charge current icon

The icon is dynamically if there is charge current.

Battery icon

The battery capacity is dynamically displayed.

Note: When the battery is in over discharge status, the icon displayed is



Battery status icons



-Normal voltage,



-Under voltage,



-Over discharge.

Load current icon

The icon is dynamically if there is discharge current.

Load status icon



- Load On,




- Load Off.

Note: In Manual Mode, pressing the "OK" button will switch the load status between "ON" and "OFF"


4. Operation


4.1 Buttons







The buttons are respectively (from left to right) “ESC”, “Left”, “Up”, “Down”, “Right” and “OK” buttons, the operation is described in the schematic operation diagram below:



Schematic operation diagram:



The default entry page is the browse mode. Pressing  button and inputt the correct password to enter the modification mode;


 and  buttons could be used to move the cursor;

 and  buttons could be used to modify the parameter values when the cursor is located at the current place;

 and  buttons could be finally used to respectively confirm and cancel the modification of the control parameters.


4.2 Main menu


Enter the Main Menu by pressing "Esc". "Up" and "Down" buttons are respectively used to move the cursor to select the menu items, "OK" and "ESC" buttons are respectively used to enter or exit the corresponding pages of the menu items.



4.3 Real-time monitoring

There are 14 pages under real-time monitoring. Please check it as below:








Operational tips:

Move between rows by pressing "Up" or "Down" buttons. Move along a row by pressing "Right" or "Left" buttons.

4.4 Device information


The product model, parameters and SN code of the controllers are displayed below:



Operational tips:  and  buttons are respectively used to turn the browse page upward and downward.

4.5 Test operation


Load switch test operation is conducted on the connection solar controller to see if the load output is normal. The test operation does not affect the working settings under actual load, which means that the solar controller will exit from the test mode when exiting the operational interface of the test.



Operational tips: Enter the page and input correct password; use and buttons to modify the On/Off status values, while use and buttons respectively to confirm and cancel the test operation.

4.6 Control parameter

Browse and modification operations are conducted over the control parameters of solar charge controller. See the scope of parameter modification in control parameters table, and the page of control parameters in the diagram below:



Control parameters table

Parameters	Default	Range
Battery type	Sealed	Sealed/Gel/Flooded/User
Battery Ah	200Ah	1~9999Ah
Temperature compensation coefficient	-3mv/°C/2V	0~-9mv
Rated voltage	Auto	Auto/12V/24V/36V/48V

Battery voltage parameters

(Parameters is in 12V system at 25°C, please use X 2 in 24V, X 3 in 36 V, and X 4 in 48 V system)

Battery charging setting	Sealed	Gel	Flooded	User
Over voltage disconnect voltage	16.0V	16.0V	16.0V	9~17V
Charging limit voltage	15.0V	15.0V	15.0V	9~17V
Over voltage reconnect voltage	15.0V	15.0V	15.0V	9~17V
Equalize charging voltage	14.6V	—	14.8V	9~17V
Boost charging voltage	14.4V	14.2V	14.6V	9~17V
Float charging voltage	13.8V	13.8V	13.8V	9~17V
Boost reconnect charging voltage	13.2V	13.2V	13.2V	9~17V
Low voltage reconnect voltage	12.6V	12.6V	12.6V	9~17V
Under voltage warning reconnect voltage	12.2V	12.2V	12.2V	9~17V
Under voltage warning voltage	12.0V	12.0V	12.0V	9~17V
Low voltage disconnect voltage	11.1V	11.1V	11.1V	9~17V
Discharging limit voltage	10.6V	10.6V	10.6V	9~17V
Equalize duration	120min	—	120min	0~180min
Boost duration	120min	120min	120min	10~180min.

Notes:


- When the battery type is sealed, gel, flooded, the adjusting range of equalize duration is 0 to 180min and boost duration is 10 to 180min.
- The following rules must be observed when modify the parameters value in user battery type (factory default value is the same as sealed type):
 - Over Voltage Disconnect Voltage > Charging Limit Voltage \geq Equalize Charging Voltage \geq Boost Charging Voltage \geq Float Charging Voltage > Boost Voltage Reconnect.
 - Over Voltage Disconnect Voltage > Over Voltage Reconnect Voltage
 - Low Voltage Reconnect Voltage > Low Voltage Disconnect Voltage \geq Discharging Limit Voltage.
 - Under Voltage Warning Recover Voltage > Under Voltage Warning Voltage \geq Discharging Limit Voltage.
 - Boost Voltage Reconnect > Low Voltage Reconnect Voltage.



NOTE: Please refer to user guide or contact with the sales for the detail of setting operation.

4.7 Load setting

The page of load setting could be used to set the four load working modes of the connection solar controller (Manual, Light on/off, Light on+timer, Time control)



① Manual control

Mode	Introductions
On	Load is on all the time if battery capacity is enough and no abnormal conditions happen.
Off	Load is Off all the time.

② Light On/Off


Light On voltage (Night threshold)	When input voltage of solar module is lower than Light On voltage, it automatically turns on load output if battery capacity is enough and no abnormal conditions happen.
Light Off voltage (Day threshold)	When input voltage of solar module is higher than Light Off voltage, it automatically turns off load output.
Delay time	The confirmation time for Light signal. During the period, if light signal voltage continues matching Light On/Off voltage, it will carry out corresponding actions (The time adjustment range:0~99mins).

③ Light On+ timer

Working time 1 (T1)	Load working period after light control turns on load	Any of the working time is set as "0", it means this time will stop working. The real working time of T2 depends on the Night time, and the length of T1, T2.
Working time 2 (T2)	Load working period before light control turns off load	
Night time	Total night time controller get from calculation (≥3h)	


④ Time control

Working time1 (T1)	Control on/off time of load through real-time clock mode.	Working time 1 is the compulsory load working time interval. Working time 2 is an optional.
Working time2 (T2)	Realize the dual timer function of the load control through real-time clock mode.	



4.8 Device parameter

The software version information of solar charge controller could be checked via the page of device parameters, and device data like device ID, device LCD backlight time and device clock could be checked and modified. The page of device parameter in the diagram below:



Note: the bigger the ID value of the connection device, the longer the Meter communication identification interval (the maximum interval < 6 minutes).

Type	Notes
Ver	Solar charger controller software and hardware version numbers.
ID	Solar charger controller communication ID numbers.
Bklight	Solar charger controller LCD backlight working time.
Month-Day-Year H:M:S	Solar charger controller internal clock.

4.9 Device password

The password of the solar charge controller could be modified via the page of device password; the device password is a 6-digit figure which is required before entering the modification mode of "Control parameter", "Load setting", "Device parameter", "Device password", "Factory reset" pages. The page of device password in the diagram below:

Device PSW

OriPsw:xxxxxx

NewPsw:xxxxxx

Note: Solar charge controller default password is "000000"

4.10 Factory reset

The default parameter values of solar charge controller could be restored via the Factory reset page, which means the “Control parameter”, “Load setting”, “Charge mode” and “Device password” of the devices could be restored to the factory defaults (the factory default password of the devices is “000000”).

<p>Factory Reset</p> <p>Yes No</p>

4.11 Failure information


The current failure information of the solar charge controller could be checked via the Failure information page (a maximum of 15 failure messages could be displayed); when the failures of solar charge controller are eliminated, the corresponding failure information will also be automatically eliminated.

<p>Failure Info</p> <p>1.Over voltage</p> <p>2.Over load</p> <p>3.Short circuit</p>

Failure information	Details
Load MOS-Short	The MOSFET of load driver is short.
Load Circuit	The load circuit is short.
Load O. cur.	The load circuit is over current.
Input O. cur.	PV input current is over rate.
RPP Short	The MOSFET of reverse polarity protection is short.
RPP Break	The MOSFET of reverse polarity protection is break.
Char.MOS-Short	The MOSFET of charge driver is short.
Input O. Cur.	Input current is over rate.
Disc.O.O.Ctrl.	Discharge operation is out of control.
Ctrlr O.Temp.	The controller is over temperature.
Comm. Timeout	The communication is timeout.

4.12 Meter parameter

The meter model, software and hardware version, and SN NO. could be checked via Meter parameter page. And the three parameters (Switch pages, Backlight) could be browsed and modified as well.



Note: When the set-up is accomplished, the auto switch page cannot become effective until ten minutes later.

Parameters	Default	Range	Remark
Sw-Pages	0	0~120S	The automatic switchover inverter for real-time monitoring page
BKlight	20	0~999S	LCD backlight time

5. Technical Specifications

Electrical Parameter

Self-consumption	Backlight <65mA
	Backlight ON<23mA
	Backlight OFF<15mA

Mechanical Parameter


Faceplate dimensions	98×98 mm
Frame dimensions	114×114 mm
Connector type	RJ45
Meter cable	Standard 2m,Max 50 m
Meter weight	Simple package: 0.23 Kg Standard package:0.32 Kg

Environmental Parameter


Ambient temperature	-20°C~+70°C
---------------------	-------------

Definitions of interface pins

Pin No.	Definition
1	Power+5~12V input
2	Power+5~12V input
3	RS485-B
4	RS485-B
5	RS485-A
6	RS485-A
7	GND
8	GND



REMOTE METER DIMENSIONS (mm)



Any changes without prior notice! Version number: V2.3



Power your life !



SolarV GmbH
info@solarv.de
www.solarv.de